

Title: Installing the Motion VI Library 2.0a with LabVIEW 6.x
Products(s): Motion VI Library 2.0a
Keywords: installation, LabVIEW, Motion VI Library
ID#: TN1040
Date: April 2, 2002

Summary

National Instruments has changed the default installation location for LabVIEW 6.x when compared to previous versions of LabVIEW. You must manually change the install directory of Motion VI Library version 2.0a to correctly install under LabVIEW 6.x. Version 2.1.0 of the Motion VI Library automatically installs in the correct directory and is the recommended solution, or you may use the following work-around with version 2.0a.

More Information

During installation you will be prompted by the following dialog box. At this time you may select Browse to choose the root location of your LabVIEW 6.x installation.



A typical installation location for LabVIEW 6.0 would be the following.

```
c:\program files\national instruments\labview 6
```

A typical installation location for LabVIEW 6.1 would be the following.

```
c:\program files\national instruments\labview 6.1
```

In comparison, a typical installation location for LabVIEW 5.0 would be the following.

```
c:\program files\national instruments\labview
```

You may have multiple installations of LabVIEW installed on a computer at the same time. However, you must install the Motion VI Library into the root of each LabVIEW installation for seamless integration of the Motion VI Library's VIs and help files.